


# CHRONOS




Quick start guide • Kurzreferenz  
Aide-mémoire • Guida rapida • Guía rápida  
Vlugge gids • Snabbguide • Lynvejledning

## 1. Aerial - Antenne - Antenna - Antena - Antenn



## 2. Power - Stromversorgung - Alimentation - Alimentazione - Alimentación - Stroom - Ström




## 3. On - Ein - Activé - Activado - Aan - På - Tænd



## 4. Volume - Lautstärke - Volumen - Volym - Lydstyrke



## 5. DAB station - Sender - Stazione - Emisora



[www.pure.com](http://www.pure.com)

PURE Digital  
Imagination Technologies Ltd.  
Home Park Estate  
Kings Langley  
Herts  
WD4 8LZ, UK



+44 (0) 1923 277477 support  
+44 (0) 1923 277488 sales



+44 (0) 1923 270188




support@pure.com  
sales@pure.com




**PURE**


## 6. Alarm - Alarma - Allarme - Alarma




## 7. Snooze - Rappel - Sospendi - Retraso




## 8. Cancel - Löschen - Annulation - Annulla - Cancelar - Annuleer - Avbryt - Annuller



## 9. Sleep - Einschlafen - Veille - Desconexión - Slaap



## 10. Presets - Belegungen - Présélections - Memorie - Presintonías - Voorafinstellingen - Förinställda stationer



## 11. Recall - Abrufen - Rappel - Richiama - Recorder - Heroproepen - Hämta - Genkald

