



PocketDAB 2000




Quick start guide • Kurzreferenz
Aide-mémoire • Guida rapida • Guía rápida
Vlugge gids • Snabbguide • Lynvejledning

1. Power - Stromversorgung - Alimentation - Alimentazione - Alimentación - Stroom - Ström




2. Headphones - Kopfhörer - Casque - Cuffie - Auriculares - Hoofdtelefoons - Hörlurar - Hovedtelefoner




3. SD card - SD Karte - Carte SD - Scheda SD - Tarjeta SD - SD-kaart - SD-kort



4. On - Ein - Activé - Activado - Aan - På - Tænd



5. Language - Sprache - Langue - Lengua - Lingua - Taal - Språk - Sprog



www.pure.com

PURE Digital
Imagination Technologies Ltd.
Imagination House
Home Park Estate
Kings Langley
Herts
WD4 8LZ, UK



+44 (0) 1923 277477 support
+44 (0) 1923 277488 sales



+44 (0) 1923 270188




support@pure.com
sales@pure.com




PURE

6. Autotune - Autotunen - Réglage automatique - Sintonizzazione automatica - Sintonización automática - Ställ in automatiskt




7. DAB station - Sender - Stazione - Emisora




8. ReVu ||



9. ReVu ▶




10. ReVu ◀▶




11. ReVu Exit - Beenden - Quitter - Esci - Salir - Uitgang - Avsluta - Forlad



12. Record (MP2) - Aufzeichnen - Enregistrement - Registra - Grabar - Opnemen - Spela in - Optag



13. Play (MP2/MP3) - Spielen - Lecture - Riproduci - Reproducir - Spelen - Spela - Spil



14. FM

